




CAPPELLO ANTIRIFLUSSO

Serve ad evitare che la pioggia e i venti disturbino il normale deflusso dei fumi.



D	De
80	180
100	200
110	210
120	220
130	230
140	240
150	250
160	260
180	280
200	300
220	320
250	350
300	400
350	450